



24.95 EUR
incl. 19% VAT, plus [shipping](#)

Support: [Drivers](#) | [Installation Guide \[DE\]](#) | [Alternative Drivers](#)

Adapter is compatible with Centrafuse.

Features:

OBD-II USB is the latest PC-based scan tool. It supports all OBD-II protocols. The output protocol (connection to laptop or car-pc) is USB.

OBD Interpreter: ELM32x compatible (320, 322, 323, 327)

OBD-II Protocols:

- ISO15765-4 (CAN)
- ISO14230-4 (KWP2000)
- ISO9141-2
- J1850 VPW
- J1850 PWM

Output protocol: RS232

Baud rate: 9600 or 38400

Indicator LEDs: OBD Tx/Rx, RS232 Tx/Rx, Power

Operating voltage: 12V, internal protection from short circuits/overvoltages

Nominal idle current: 45 mA

Drivers : <http://www.ftdichip.com/Drivers/VCP.htm>